



ELEVATION

METHOD OF TYING FENCE TO HEADWALL


GENERAL NOTES:
ALL POSTS AND BRACES MAY BE EITHER ROUND OR SQUARE AT THE OPTION OF THE CONTRACTOR, PROVIDED THE SAME TYPE IS USED THROUGHOUT THE PROJECT FOR POST AND BRACE.
DIMENSIONS SHOWN ARE THE DIAMETER OF ROUND POSTS OR EDGE DIMENSIONS OF SQUARE POSTS.
INSTALL THE FENCE FACING THE PROPERTY OWNER EXCEPT THAT ON HORIZONTAL CURVES GREATER THAN THREE DEGREES; INSTALL THE FENCE TO PULL AGAINST ALL POSTS.



PLAN



METHOD OF ERECTING FENCE FOR
FILL SLOPE



PLAN VIEW